


Installation & User Manual



ZM6 Voltage Regulator – Version 2

Note: Version 2 is from serial number 700 onwards

Table of Contents

Table of Contents	2
Features	3
Alternator Modification	4
Alternator Size.....	5
Installation tips.....	6
ZM6 Specifications	7
How the ZM6 works.....	8
Top of board controls.....	9
Bottom of board controls.....	10
Board controls - Adjustments.....	11
Installation.....	12
Installation – Diagram.....	13
Installation check list	14
Set up	15
Set up, continued.	16
Suggested set voltages	17
Changing ratio.....	18
Current Limiter Adjustment	19
Changing Overvoltage sense.....	20
Setting Absorption time.....	21
Setting External temperature. (optional).....	22
FAQ – Frequently Asked Questions.....	23
Fault Finding	24
Product Liability.....	27
Warranty Details.....	27
Phone Assistance.....	27
Contact Details.....	28

Features

- An easily adjustable voltage setting to accommodate different battery chemistries.
- Suitable for 12 and 24-volt system voltages (controlled by jumpers)
- Will regulate any N-type or P-type alternator (controlled by removable fuse).
- A soft start to ease the sudden inrush of current.
- Fault protection for, low voltage and overvoltage, in this event the field shuts down, CLEAR button for a manual reset of system. Fault detection is delayed for 9 seconds during initial power up, once running a fault detection is a ½ second delay.
- Current Limiting protection for external and internal temperature faults, in this event the field current drops down to an adjustable figure (12.75v – 13.75v) until such stage as the temperature drops to an acceptable level. A fault condition is indicated by the illumination of an ORANGE LED.
- ABSORPTION and FLOAT stages, indicated by LEDs to show state, can be selected as required, if float voltage is wanted earlier in the engine operation, push FLOAT button conversely if a longer Absorption cycle is needed push the ABSORPTION button
- A BLUE Led indicates field output.
- A GREEN onboard LED flashes to indicate the oscillator is running, only during Absorption phase.
- 24-month warranty, we will repair or replace free of charge. This warranty does not include damage resulting from incorrect installation, accident, misuse, or neglect. The warranty is void if the unit is tampered with, freight is not covered.
- Designed, built, and supported in New Zealand.
- Circuit boards are treated with Conformal coating material to protect against moisture, dust, chemicals.
- See ZM6 operation and set up video on at "YouTube", search "ZM6 Smart Regulator"

Alternator Modification

N or P? there is no performance difference or advantage it is more an alternator manufacturer's choice.

Some alternators are best suited to the P-type but the majority are N-type.

The objective is to have the ZM6 N control the negative side of the brush block

The ZM6 N is a negative brush control system, this means that the positive brush requires power at all times and the theory is we control the negative brush which controls the output of the alternator as per the setting on the ZM6. This is also known as A type

The objective is to have the ZM6 P control the positive side of the brush block

The ZM6 P is a positive brush control system, this means that the positive brush is the field control and the negative brush is earthed. This is also known as B type.

Modification of your existing alternator to accept an external regulator is a requirement and can be done by yourself or a reputable auto electrical shop. Depending on your alternator type, an external brush block is available from us or most auto electrical shops.

We also offer a service to modify your alternator.

We have available on the download section of our website instructions for different alternator conversions to accept an external regulator.

Alternator Size


I always recommend a Bosch 80- 120-amp alternator, which is about the highest rating without going into high priced alternators.

No matter how good any smart regulator is, if the alternator is not spinning fast enough then you will not get a good charge current into your battery bank.

You need to calculate what your lowest cruising rpm is and arrange your pulley size to ensure your alternator is producing the best possible output, absolute minimum is 2500 alternator rpm.

Remember, for every 25 amps you will draw 1hp power of engine energy.

The following photo shows alternator brush orientation



Installation tips

Make sure your pulley ratios are correct for your cruising rpm, i.e., the alternator needs to be turning at least 3000 rpm, and preferably 5000 rpm and up to 8000 rpm for a decent charge to be outputting from your alternator.

Ensure your earth leads from the engine block to the alternator and starter are not used via the block. If there is any high resistance the earth trace will find itself tracking through your engine bearings and could cause arcing. Get peace of mind and run separate earth leads.

Try to use the same type of batteries i.e., Lead-acid /Gel / AGM. Don't mix them up.

Your installation should have two battery banks, one for starting and one for house loads.

Charge batteries in parallel, using a voltage-sensitive relay.

Make sure your engine has enough "belt" to drive the alternator you select.

Do not leave batteries discharged for extended periods, exception LifeP04.

Plan your battery capacity to ensure your house batteries are run no less than 50% of capacity.

Provide a means to cross-connect battery banks for emergency starting.

Protect circuits with fuses or circuit breakers.

Voltage drop is the enemy, look to find the offending connections and fix them.

Connecting batteries in series, the amp-hour capacity remains the same as a single battery however the voltage is doubled.

Connecting batteries in parallel, the amp-hour capacity is doubled and the voltage remains the same as a single battery.

An alternator has a huge fan that draws air from the BACK to the FRONT of the alternator for cooling; imagine if this air has salt-laden air in it, this will cause corrosion in non-marinated alternators. Consider getting the internals painted in good quality paint to get a longer life out of your alternator.

Automotive 'in line' ammeters are a huge voltage drop in your charging system. If your system charges at a low current charge and quickly drops down to 10 amps it is most probably the 'in line' ammeter at fault. The best option is a 'shunt' type ammeter.

NEVER turn OFF the battery switch with the engine running, it can blow up the alternator and or the smart regulator.

ZM6 Specifications

Voltage	12- volt or 24-volt (switched via jumper)
Polarity types	"N" or "P" switching (switched via fuse)
Charging stages	Bulk – Absorption - Float
Adjustable ratio Absorption to Float	Yes, adjustable by user (0 to 2 volts)
The factory setting for ratio	(12v) 0.6 volt - (24v) 1.2 volts
Approximate time at the Absorption rate	0-140 minutes (20-minute increments)
Absorption Indicator	Yellow LED
Float Indicator	Green LED
Alternator range	0–350-amp alternator (brush or brushless)
Maximum Continuous Field current	5 amps (most alternators are 2-4 amps)
12-volt version voltage adjustment range	12 to 15.5 volts
The factory setting for voltage regulation	(12v) 14.7 volts - (24v) 29.4 volts
24-volt version voltage adjustment range	24 to 32 volts
Reverse polarity protection	Yes
Overvoltage protection	Yes, adjustable by the user, a RED LED to indicate overvolt and unit will shut down field
The factory setting for overvoltage protection	(12v) 15.5 volts - (24v) 31 volts
Overtemperature current limiting protection	Derates output until condition of over temperature reverts to normal. Indicated by ORANGE LED 12.75 v to 13.75v adjustable range
Low voltage protection	Shuts off FIELD control (factory set 10.6v)
Minimum Ignition input voltage	11.0v
Overvoltage Indicator	Red LED and buzzer (supplied)
Unit size	167mm long x 43mm high x 100mm wide.
Weight	250 grams
Fuses (Field)	Fitted inside unit 5-amp mini blade
Fuses (Ignition) draws less than 500ma	Ignition recommend 5 amp
Fuses (Battery sense) draws up to 5amps	Battery sense recommended 5 amp

How the ZM6 works

Broadly, the ZM6 regulator consists of a timer block, voltage comparison logic, and a Darlington transistor output stage.

The timer block is responsible for overseeing the transition between the absorption and float stages, and is user selectable in 20-minute increments (factory set 120 minutes)

The voltage comparison logic continuously monitors the battery voltage and compares it to the voltage level you have selected with the adjustment control. The analogue signal is modulated by an oscillator to feed the pulse frequency modulation signal for regulation whereby the Darlington transistor is turned on and off based on the output voltage as it changes, sensed by the oscillator.

Once the voltage level has been raised back to your setting, the field current is disengaged. Hysteresis is built into the comparison logic to ensure the feedback loop remains stable.


A slight amount of current is held to ensure that the ignition light does not come on.

The unit design has an overvoltage, undervoltage, that disables the FIELD circuit.

The over temperature of either alternator or internal output transistors, will derate the output until such stage that condition reverts back to an acceptable condition, this will continue to cycle on and off until such time as temperature stabilises. The current limiting is user adjustable for a fault condition.

Control of reverse polarity is also built into the new design.


Any type of alternator can be run by this regulator, providing **field** current draw does not exceed 5 amps continuous or 8 amps intermittently, most run at 1-2 amps.



Graph showing pulse frequency modulation versus load.


Top of board controls

- (1) **Absorption Time Dip Switch** – This allows user defined absorption time 0-140 minutes.
- (2) **Absorption Switch** – to force Absorption mode
- (3) **Absorption LED** (Yellow) to indicate system is in absorption mode
- (4) **Ratio** – Adjusting voltage between Absorption and Float settings,
- (5) **Float Switch** – to force Float mode
- (6) **Float LED** (Green) to indicate system is in float mode
- (7) **Overvoltage Adj** – RED LED for overvoltage situation.
- (8) **O V V** – Overvoltage adjustment test point
- (9) **High LED** – Red Led indicates over voltage
- (10) **CLEAR FAULT** –, Push button, Overvoltage /undervoltage / if a fault is detected system will disable the field circuit, solve the issue and reset by pushing button.
- (11) **Temp EXT** – External temperature adjuster, refer in following pages on adjustment process
- (12) **INTERNAL HOT** – ORANGE LED Indicates an overtemperature/fault on internal components linked to output stage. This is pre-set to 38 degrees C and would typically indicate an alternator problem.




Bottom of board controls

- (14) **VOLTAGE ADJ** – For adjusting set voltage, (this is what you will use on a regular basis)
- (15) **LOW VOLTS LED** – to indicate low battery voltage 10v or 20v for 24-volt versions.
- (16) **BATT SPADE** – Battery sense wire via a 5-amp fuse.
- (17) **IGN SPADE** – Ignition feed wire via a 5-amp fuse.
- (18) **GND SPADE** – Ground or earth.
- (19) **FIELD SPADE** – Field terminal to alternator (on board fuse)
- (20) **FIELD LED** – This indicates a FIELD output on, will flicker.
- (21) **BUZZ + SPADE** – for the supplied buzzer unit, polarity not important.
- (22) **BUZZ – SPADE** - for the supplied buzzer unit, polarity not important (11v output)
- (23) **TEMP – SPADE** – if optional temp probe, polarity not important.
- (24) **TEMP + SPADE** - if optional temp probe, polarity not important.
- (25) **EXT OVERTEMP LED** – This ORANGE Led will illuminate if an overtemperature occurs and the field will be isolated



Board controls - Adjustments



Installation

Mount the unit preferably remotely from the engine bay to ensure a clean dry, cool environment. Connect **NO** bigger than 14 gauge (2.5mm) (7.5amp) tinned wires to the following terminals.

A maximum of 4 metre FIELD wire distance from the alternator to ZM6 due to inductive switching of field, or else voltage fluctuations may occur.

BATTERY (16): Connect this terminal directly to the positive side of the battery. If you have two batteries i.e.: a start and house, suggest you connect it to the house battery, this will prevent any spikes from high drain current items like starters, etc. Suggest you use a red wire for this terminal, or mark the wire clearly. You should connect this wire with an inline fuse (5 amp) **Do not connect via any switch.** If you have a diode block, make sure you sense on the opposite side of the unit, if you're unsure, check for voltage on B+ alternator terminal, if zero you most probably have a diode block

IGNITION (17): Connect this terminal to the ignition switch. To avoid confusion a suggested colour is Yellow or mark the wire clearly. You should connect this wire with an inline fuse (5 amp) located close to the ignition switch. **Do not connect the IGN to the D+ terminal of the alternator.**

EARTH (18): Connect this terminal directly to a good negative supply bus bar. If you are unsure place, it directly on the negative post of the battery, suggest you use a black wire for this terminal, or mark the wire clearly.

FIELD (19): This unit controls the field side of the brush block. Connect this wire directly to the alternator field terminal, once the alternator has been converted.

BUZZER (21) + and (22)-: If using the optional supplied buzzer/ light, unit then the polarity is not critical. Maximum current draw 11 volts at 1 amp for any device connected. If you do not use the buzzer and the unit shuts down for any reason, start by resetting the clear button.




If you are unsure if your alternator is configured correctly do the following test:

Remove the field wire from ZM6 N and with the engine idling, briefly (2-4 seconds) hold the alternator field wire to earth.

Field to positive for ZM6 P.

Note: you will get a spark. You will hear the engine load up and the output voltage should quickly rise, this indicates the alternator is configured correctly.

Installation – Diagram



Installation check list

If you choose the “Works” option at purchase we will complete most of the below settings and a copy of our worksheet is supplied. If not, the factory setting is 12 v system, 14.7v Absorption, 14.0 Float, 80 degrees temp setting and 15.4v overvoltage.

House battery should be fully charged before configuring unit, this will allow for more stable setting. ZM6 settings should be done at normal cruise rpm., not idle rpm.	
Alternator configured for correct field polarity, P or N switching, see Page 4	
Wiring to ZM6 installed per instructions, fuses in place, page 13, check ignition input voltage, must be above 11volts	
If unsure of polarity, and BEFORE connecting the ZM6, carry out test per Page 24	
ZM6 configured for correct voltage, 12v or 24v system using two jumpers page 15	
ZM6 configured for correct field polarity, P or N switching fuse, Page 16	
Temperature probe fitted (optional) see Page 19 for set up (default is 80 degrees)	
Absorption DIP switch set to time at Absorption for the correct battery type, pg21	
Buzzer installed (recommended)	
Start engine, push FLOAT force button, check Green LED on and Field LED on after 20 seconds of operation. See page 15	
Adjust lower float voltage using VOLT ADJUST potentiometer	
Let voltage stabilise for a period of time and fine tune voltage setting, you might need to check over a period of several trips to make sure it has stabilised.	
Force ABSORPTION button, Yellow LED should be on and green LED on board should be flashing, this is normal and NOT a fault indicator.	
Adjust Absorption voltage using Ratio potentiometer stabilise for a period of time and fine tune voltage setting	
Whilst at set Absorption voltage check battery overvoltage setting 5.95 to 6.0 volts, this will provide an overvoltage trip of 15.2 to 15.4 volts	
Short out two temperature probes and check that the Orange LED illuminates and voltage drops to approximately 12.75 to 13.75 volts. Factory set to 13.75 volts	
Reset system by pushing CLEAR button, check field LED on and charging	
We strongly recommend that as soon as you get started, do the running Alternator Diode Test (Page 25) of this manual, there are a number of times the ZM6 indicates an internal fault in the ZM6, this is typically an alternator issue.	

Set up

It is suggested that you start this process with fully charged batteries. This will provide a stable platform for setting the ZM6 'set voltage'.


The charge voltage is factory set to (29.2v) 14.7 volts Absorption and (27.8v) 13.8 volts Float and the overvoltage is set to (30.5v) 15.5 volts. All set with a 5 -10 amp load You will need to fine tune the adjustments to take care of voltage drops in your own installation as they do vary.

Note: Before powering up the unit the ZM6 board must be configured for the correct voltage and correct alternator field polarity as follows:

- 1/ Remove the top cover of the ZM6 by removing the four corner screws.
- 2/ **NOTE; Do not touch any of the Integrated circuit (ICs) as static electricity on your hands could damage the chip**
- 3/ With the spade terminals facing the bottom, and looking at the board there are two jumpers on the bottom right corner. For 12volt operations the jumpers should be ON. For 24-volt operations the jumpers must be removed. (Default 12v, jumpers ON)



Set up, continued.



4/ On the top left side there are two fuse holders being Left side for positive switching alternators, and the right-hand fuse holder is for negative switching alternators. (Default P)

NOTE: Only One fuse should be in at any one time, failure to adhere to this will short circuit the output stage.

5/ We suggest you carry a spare mini blade fuse of a 5-amp value

6/ Start engine and immediately select FLOAT by pressing float switch (5), then adjust lower float voltage to desired setting by adjusting Volt Adjustment potentiometer (14), wait for voltage to stabilise and fine tune as required.

7/ Press Absorption switch (2) and adjust upper voltage to Absorption voltage by means of the Ratio adjuster (4) to the desired setting, let stabilise

8/ Whilst at Absorption voltage, adjust overvoltage (7) setting to 5.95 to 6.0 volts (8)

9/ refit top cover and then the unit is ready for service.

Note: all screw adjustments are Clockwise to increase range, Counter clockwise to decrease range.

Suggested set voltages

12 VOLT UNITS

Suggested Set Voltages	From	To
Lead Acid and AGM (Absorption Setting)	14.6 V	14.9 V
Lead Acid and AGM (Float Voltage)	13.8 V	14.0 V
Gel Cell (Absorption Setting)	13.9 V	14.4 V
Gel Cell (Float Voltage)	13.1V	13.8 V
LifeP04 (Absorption Setting)	14.0 V	14.3 V
LifeP04 (Float Voltage)	13.5 V	13.7 V

24 VOLT UNITS

Suggested Set Voltages	From	To
Lead Acid and AGM (Absorption Setting)	28.4 V	29.6 V
Lead Acid and AGM (Float Voltage)	27.2 V	28.4 V
Gel Cell (Absorption Setting)	27.6 V	28.4 V
Gel Cell (Float Voltage)	26.4 V	27.2 V
LifeP04 (Absorption Setting)	28.0 V	28.6 V
LifeP04 (Float Voltage)	27.0 V	27.4 V

Remember to set the voltage at your normal cruise rpm if possible and only adjust after the battery level has stabilised.

If you have a lead-acid battery with vented caps then you can set the voltage to the upper limit. If the battery is 'maintenance free' sealed type then you will need to set the voltage to the lower end of the scale.

For marine installations, setting the ZM6 whilst in dock will always see a shift when you are out at sea, just monitor and adjust as required on your first trip out with normal loads on.

Once you have this set, there should not be any further adjustments required.

The above is only a guide, check with your battery manufacturer.

Changing ratio

The function of the ratio is to set the relationship between Absorption voltage and Float voltages, once set any change of the VOLT ADJ will provide a corresponding change to the Float voltage.


The unit has been factory set to provide a ratio of 0.7v between the Absorption and Float rates. Some AGM batteries require a 1.0v ratio. To change this ratio, proceed as follows;

1/ Note: all screw adjustments are as follows, clockwise to increase, counter clockwise to decrease.

2/ with the engine running at normal cruise rpm and normal load applied push the FLOAT push button (5), the **Green** Float LED (6) should be **On**. Adjust the VOLT ADJ potentiometer (14) to the desired **lower** voltage, let's say 13.7v, stabilise and ensure voltage steady on the desired figure. Each turn of the VOLT ADJ pot is equal to approximately 0.12volt change.

3/ Push the Absorption button (2), the Yellow Absorption LED (3) should be **On**

4/ You then adjust the RATIO potentiometer (4) to the desired **upper** voltage, say 14.7v, stabilise for 5 minutes and ensure voltage steady on the desired figure. Each turn of the RATIO pot is equal to 0.6volt change.



Current Limiter Adjustment

The system is designed to derate the unit to a lower voltage / current output whilst the condition of over temperature remains. This control is for both internal and external temperature sensing.

The factory default will show as a range of 12.75 volts to 13.75 volts and the current will depend on capacity of the alternator/battery combination.


To adjust this value there is an onboard adjuster (shown on the below graphic)

Start by shorting out the temp pins, this will force the fault condition, Orange LED on.

Adjust when in Absorption mode.

Clockwise to increase and anticlockwise to decrease the value.

If in a fault condition (ORANGE LED ON), and the ZM6 is cycling quickly between the temperature limit it would be prudent to lower the setting to prevent damage to the system components being the ZM6 / alternator and possibly the battery.



Changing Overvoltage sense.

The purpose of the overvoltage function is to set a predetermined voltage value that in the event of reaching that higher voltage the system shuts down the field output until the situation is restored and the CLEAR button is pressed.

Adjusting threshold Method 1

1/ Using a digital volt meter using the "+" probe on the test point labelled "O V V" (8) located behind the LED "High".

The "-" probe on the GND test point and with unit powered up and at normal operating voltage.

2/ Adjust the "O V V" potentiometer (7) to obtain between 5.95 to 6.0 volts at test point "O V V" at your Absorption voltage set.

Adjusting threshold Method 2

1/ Adjust the "O V V" adjusting potentiometer (7) in (clockwise) 2 turns to take it well out of range.


2/ Set "Volt Adj" (14) voltage at 14.5 volts (29 volts)

3/ Adjust over-voltage screw (7) out slowly (counter clockwise) until the RED LED (9) illuminates and warning buzzer activates.

4/ Adjust over-voltage screw in 1 turn

5/ Reset by pushing the CLEAR push button.

Note, slight glowing of the OVV LED is normal, if you trip the system make sure you reset by pushing CLEAR



Setting Absorption time.

The purpose of the Absorption time is to preselect a time for the unit to hold the voltage at the Absorption voltage, after that pre-set time the unit will go to the float voltage previously selected. At any time, you can toggle between Float and Absorption

The unit is factory set to 120 minutes

You can select any of the following combinations to obtain zero minutes to 140 minutes absorption time and stepped in 20-minute increments.


Note: 20 minutes plus or minus 2% minutes

A 3-position dip switch (1) is the method to change timing duration.

Typically for most batteries 120 minutes is sufficient with the following exceptions:

- 1/ LifeP04 – look for 20 to 40 minutes maximum absorption time
- 2/ smaller battery banks < 100amp hour – look at 40 to 60 minutes
- 3/ Older Lead acid or AGM > 120 minutes
- 4/ big battery banks > 250amp hour 140 minutes

Minutes	SW1	SW2	SW3
0			
20			ON
40		ON	
60		ON	ON
80	ON		
100	ON		ON
120	ON	ON	
140	ON	ON	ON



Setting External temperature. (optional)

For those wanting to make their own temp probe it is simply a matter of connecting a 10k NTC to the ZM6. An NTC can purchased from the likes of Jaycar (RN3440)

The unit works by sensing the resistance of the temp bulb, once the pre-set temperature is reached the unit will shut down the field output, once the temperature drops as indicated by the LED, the user must manually reset by pushing CLEAR

For those replacing an Ample Power unit DO NOT use the existing temp sensor probe as it is the wrong resistance value.

To calibrate, this can be done by connecting set known resistor values across the two terminals. Supplied with the optional temperature probe are 2 x resistors set for 50 degrees and 90 degrees. Or you can use the likes of a rice cooker and temperature gauge to accurately set to your desired temperature using the temperature probe.

For battery monitoring 50 degrees is the recommended maximum

For alternator monitoring 80 to 90 degrees is the recommended maximum

If you desire any other temperature setting here is the values required

Desired temperature	Resistor value
50	3K3Ω
60	2K4Ω
70	1K8Ω
80	1K2Ω
90	912Ω

Process of setting desired temperature range

- 1/ disconnect the field wire (19) from the ZM6 to prevent the alternator field activating
- 2/ power up the unit
- 3/ place the desired resistor value on the pins Temp+ (23) and Temp – (24) (Note: polarity not important)
- 4/ Adjust the temperature External (11) adjuster to just have the overtemperature LED (25) illuminate and buzzer will sound. Clockwise for increase temperature, counterclockwise to decrease temperature. Once the ORANGE LED goes out, push the CLEAR button.
- 5/ remove resistor, push CLEAR button if no field LED on (10)
- 6/ Reconnect the field connector to the ZM6 with the unit powered down

As a suggestion for battery monitoring, connect to the negative battery post

For alternator monitoring the ideal place is the alternator stator however securing is not easy so an, aft through bolt is sufficient, but you will need to check the difference between the probe location and the hottest part of the alternator which is generally the stator, use an infrared thermometer.

If you have an external BMS for LifeP04 batteries or any other monitor for voltage exceedances, you can connect across the temp probes to act as another method to derate output.

FAQ – Frequently Asked Questions

Q	What wiring changes are required on my existing installation?
A	As well as running a wire to your alternator field terminal, you will need an ignition source to the ZM6 and a battery positive wire and an earth wire.
Q	Will this unit work through a VSR (Voltage Sensitive relay)?
A	Yes. A good way to allow dual battery charging, sense off the house battery.
Q	Will this unit work through a diode splitter?
A	Yes. The ZM6 can compensate for the typical voltage drop over a diode bank, providing that the battery sense wire is on the battery side of the diode bank.
Q	Can you refurbish my alternator and convert it to an external regulator?
A	Yes, we do this regularly for clients.
Q	Can I modify my alternator?
A	Yes. It is a matter of running a field wire to the appropriate side of the brush block. The ZM6 N controls the earth side of the brushes. The ZM6 P controls the positive side of the brushes.
Q	What is the difference between N and P switching?
A	Certain manufacturers elect to switch the positive brush whilst the majority of others switch the negative brush, as a user you do not know the difference in an operational sense.
Q	Why does the RED / ORANGE LEDs glow slightly during operation?
A	As the voltage/temperature near the trigger threshold the LED will glow slightly, this is normal and nothing to worry about.
Q	There is a Green LED flashing on the inside of the unit?
A	This LED flashes with the onboard oscillator which will run when in Absorption mode only, it is normal function of the unit.
Q	What is the field LED function and will it indicate a blown fuse on the field line?
A	The purpose of the field LED is to indicate that the ZM6 microprocessor is outputting a field current. It is located downstream of the fuse so will NOT indicate a failed field fuse (5 amp)
Q	The unit is powered up and the system does not charge and there are no fault LED's on nor is the field LED on?
A	Push the CLEAR button or reset ignition, a previous fault has shut down the system and requires resetting.

Fault Finding

Write down the circumstances leading to the discovery that a problem exists. Make it as clear as possible. If you're not charging, and you have just installed a new alternator, suspecting the regulator is faulty may not be the best decision. Wiring errors or compatibility issues between the alternator and regulator are prime suspects. We are happy to work through any charging issues you have, but please do the basic fault finding first. The majority of faults reported are wiring installation issues.

No Alternator Output

Check that the blue Field LED is on with the unit powered up, push the CLEAR button to make sure no fault exists, is the BLUE Field LED on?

Check FIELD fuse inside unit

Check to see if there is a voltage supply to the IGN terminal on ZM6, Absorption LED should be ON.

Is the ignition light connected and working correctly, i.e., is the alternator 'excited'? Check fuses.

If the BLUE Field LED comes on and then goes out, start again and watch which of the four possible trip LEDs comes on (Briefly) to indicate where the fault lays.

We have several cases of the IGN voltage slumping during start to below 10.4v which will trip out the unit, in this case use a relay from a battery supply to feed the ignition spade terminal. Or as a test, bridge Battery and Ignition and see if the unit operates without faulting.

To Test alternator

Remove the field wire from ZM6 N and with the engine idling, briefly (2-4 seconds) hold the alternator field wire to earth. Note: you will get a spark. You will hear the engine load up and the output voltage should quickly go towards 16v+. Stop the test before any overvoltage occurs and you are sure of getting a voltage rise

Remove the field wire from ZM6 P and with the engine idling, briefly (2-4 seconds) hold the alternator field wire to positive. Note: you will get a spark. You will hear the engine load up and the output voltage should quickly go towards 16v+. Stop the test before any overvoltage occurs and you are sure of getting a voltage rise

This would indicate that the alternator is fine and the ZM6 is at fault.

Another way of checking the field output of the alternator, is to put a small wattage bulb (incandescent) between FIELD and BATT on a ZM6 N or between FIELD and EARTH for a ZM6 P and again adjust the VOLT ADJ pot. You should see light come on. However, the battery voltage must be above 13.6 volts for this test to work.

A very common issue is lack of excitation of the alternator via the D+ terminal. This can be checked by turning on Ignition and using a steel blade of a screwdriver see if the rotor shaft is magnetised, this will indicate that the field is excited.


If you are unsure run a wire from B+ to the D+ for the purposes of fault finding.

Internal hot indication

This sensor has detected that either of the two output transistors are in excess of 48 degrees C Which means that there is an alternator fault or some internal fault. The unit will go into current limiter mode and as such time as the ORANGE LED goes out you will not get full output. Typically, our experience is been an alternator fault not a ZM6 issue, check all your earth leads as this can create the fault, also carry out the following test.

Alternator Diode Test

- Using a digital volt meter, set to AC volts **(Note must be AC not DC)**
- Using the red and black test leads probe between B+ and alternator ground, Red to B+ Black to Ground, note reading, should be 0.0v
- Voltage should be below 0.5v AC
- Reverse those two connections, Black to B+ and Red to Ground, note reading, should be 0.0v
- If any greater than 0.5vAC your alternator diodes are at fault and need to be rectified as they will damage delicate electronics on board, including the ZM6



Product Liability

In no event shall we be held liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life whatsoever, arising out of installation or misuse of our products. Please ensure installation is as per our installation instructions.

Warranty Details

This unit is covered by a 24-month warranty on a return-to-base basis.

We will repair or replace free of charge; we will not offer an exchange service.

Freight charges to return units are not covered by warranty.

The warranty does not include damage from incorrect installation.

The warranty is void if the cover is removed or if the unit is tampered with.

A full refund will be provided to any goods returned to our facility, in their original packaging, and within 30 days and if the goods have not been used. If goods have been used or installed and powered up then a recertification fee of up to 15%, will apply. This is to ensure no damage has occurred during installation and power up.

Shipping expenses, in both directions, are not refundable.

Phone Assistance

We are happy to provide telephone support, however, we are not mind readers and you will get asked "did you follow the fault-finding section" before you ring our office!

Also do read the FAQ as we try to include topics whenever people experience problems.

When you do make contact please provide as much information about your installation so that we can best assist with fault finding.

You can save yourself (and I) a lot of grief if you have done this, before ringing, and remember everyone blames the "little black box" first before looking at other components in the loop!!

As the old saying goes RTFM

Contact Details

For any questions or warranty matters contact:

Graeme Polley
49 Sunnyhills Avenue,
Glenview, Hamilton 3206
New Zealand.

International Phone: +64 274 487 027

Local NZ Phone: 0274 487 027

Email: info@smartregulator.co.nz

The latest revision of this manual can be obtained from our website

www.smartregulator.co.nz