



New ZM4 field wire

Cut this link here, and solder a 150mm wire to the top part of the cut, for ZM4 FIELD terminal

Use a round file and allow a gap for the field wire to exit