



This is a suggested set up with single engine installation, Make sure ZM4 BATT is connected to house battery.  
 Make sure VSR (voltage sensitive relay) is earthed.

ZM4 Single Engine VSR	
19/01/2015 9:24:08 a.m.	
Sheet: 1/1	